

*marble***VISIONS**

cultured bath products

HOW TO CARE FOR YOUR CULTURED MARBLE, ONYX OR GRANITE PRODUCTS

Do **NOT** use plumbers putty when installing drains in vanity tops, tubs and shower bases. Use **ONLY** silicone when installing drains.

REGULAR CLEANING: Always clean with a non-abrasive cleaner such as Mr. Clean or a foam or gel cleaner. Use a soft cloth or sponge to clean.

To remove a build-up of soap residue, use a product called SCUMBUSTER. Wiping your shower and tub walls with a squeegee or a towel after each use keeps them spotless and will make your weekly cleaning much easier.

SHOWER FLOORS with a pebble finish can be cleaned with non-abrasive cleaners and a soft-bristled (nylon) brush.

WHIRLPOOL TUBS water lines can be cleaned periodically with a water and vinegar solution by filling your tub and running your jets. The eyeball of the jets can be removed by simply turning them counter-clockwise and removing them. This will allow for extensive cleaning.

POLISHING every few months with GEL GLOSS helps maintain a lustrous finish and makes regular cleaning even easier.

MINOR SURFACE SCRATCHES can be removed using a soft cloth and a polishing compound like MIRROR GLAZE. Use the finest grit compound available.

If more serious chips or scratches occurs, it **MAY** be repaired, sanded and buffed by a professional refinisher

PREVENTING DAMAGE TO YOUR CULTURED PRODUCT do not use strong chemicals such as bleach or ammonia to clean. Chemicals such as paint removers, drain cleaners, nail polish removers, hair colours can damage the surface. If spills occur, flush the surface with soapy water immediately and clean as usual.

To prevent minor scratches do not permit heavy or pointed objects to strike the surface. Do not drag objects across the surface.

CAUTION Flat Irons/ Curling Irons will burn the surface if left on vanity for an extended period.

HOT WATER Avoid rapid temperature changes when using your tub or vanity top. Avoid excessive high temperatures when using your cultured products. Always use a MIXTURE of hot and cold water when using your tub or vanity top.

FOLLOWING these few guidelines will give you years of trouble free use from your cultured product.